







INSTALLATION GUIDE:

For more information about how to instal your vehicle, come visit our youtube page on
<http://www.youtube.com/spyderauto>

SPYDER

Parts Identification:		TOOLS REQUIRE	
1 Piece Crystal Headlight with L.E.D.'s		Panel Popper	
Center Front Grille (Fitment with 1 Piece Headlight)		Pliers	
Center Covers			
4- Grille Clips			

STEP:

Remove the Plastic engine cover from under the hood. Use the panel poppers to remove the clips.

Once you remove the cover, take the grille apart. Using a plier, press on the clip on the rear to pull the grille out easily. There should be 5 clips holding the grille.



Remove the Headlight and Corner Light from the vehicle. There is one pin that hold the headlight and a clip that holds the corner light. When you remove the housing, unplug the light sockets but leave the light bulb on the headlight.




Transfer the bulb from the factory headlight to the new headlights. The top is Low beam, the bottom is high beam. Once you put the bulbs on, return to the truck and insert the turn signal, daytime running lights, and parking lights onto the socket.



When installing the Headlight, insert from inside where the side bracket is showing, as shown in the picture



Align the bracket and hook from where the arrow is pointing at. (arrow 1) is the clip, (arrow 2) is the hook.



Insert the new clips on the grille, the longer clips is on top and the short one is on the bottom.



STEP:

The Grille should snap into place on the frame with the new clips.



Pull the piece off from the Cover and insert it onto the grille as shown on the picture.



To connect the L.E.D., splice to the parking light for better look.



SPYDER

www.spyderauto.com